



Ford 4R100 1/2" / Chevy 3/8" Transmission Cooler Install - P/N# 1031621

#	P/N	Description	#	P/N	Description
2	1300349	14-18ga Posi-Tap	12	1400113	Insulated Clamp
3	1330109	12ga Fuse Holder w/ 15a Fuse	13	1100113	Nut (1/4")
4	1300610	Temp Sender Assy	14	1100111	Flat Washer (1/4")
5	N/A	Comes with above sender assy.	15	1100112	Lock Washer (1/4")
6	1604054	1/2" Transmission hose	16	1100110	Bolt (1/4" x 3/4 ")
7	1400105	Fitting; 1/2" Barb x 1/4" NPT f/m	17	1300130	Tie Wrap (Long)
8	1400121	Fitting; 3/8" NPT x 3/8" Tube	18	1300131	Tie Wrap (Medium)
9	1400129	Fitting; #8 JIC x 1/2" Tube 90°	19	1300132	Tie Wrap (Small)
10	1604042	Fitting; #8 F/M Hose x 1/2" Barb	20	1607009	Self-Tapping Metal Screw
11	1330149	Hose Clamp			